

Technote 162—Reversal of impedance check values on DB4 front panel display.

The values displayed on the front panel of the DB4 in impedance check mode are reversed. The value displayed following the “+” sign is the impedance for the negative (black) input, the value following the “-“ sign is the impedance for the positive (red) input. The LEDs display on the HS4 headstage during impedance testing and the polarity of the recordings is otherwise correct.